



Tetracyclines ELISA Kit

Catalog Number. CSB-E12090f

This immunoassay kit allows for the in vitro quantitative determination of Tetracyclines concentrations in honey, tissue(chicken, pork).

This package insert must be read in its entirety before using this product.

If You Have Problems

Technical Service Contact information

Phone: 86-27-87582341

Fax: 86-27-87196150

Email: tech@cusabio.com

Web: www.cusabio.com

In order to obtain higher efficiency service, please ready to supply the lot number of the kit to us (found on the outside of the box).

PRINCIPLE OF THE ASSAY

This assay employs the competitive inhibition enzyme immunoassay technique. The microtiter plate provided in this kit has been pre-coated with Tetracyclines antigen. Standards or samples are added to the appropriate microtiter plate wells with Tetracyclines specific antibody and Horseradish Peroxidase (HRP) conjugated anti-antibody. The competitive inhibition reaction is launched between pre-coated Tetracyclines and Tetracyclines in standards or samples with the Tetracyclines special antibody. A substrate solution is added to the wells and the color develops in opposite to the amount of Tetracyclines in the standards or samples. The color development is stopped and the intensity of the color is measured.

DETECTION RANGE

0.05 ppb-4.05 ppb

SENSITIVITY

The minimum detectable dose of the kit is typically less than 0.05 ppb.

The sensitivity of this assay, or Lower Limit of Detection (LOD) was defined as the lowest concentration that could be differentiated from zero.

CROSS-REACTION RATE

Tetracycline	100%
Minocycline	125%
Rolitettracycline	110%
Aureomycin	100%
Demeclocycline	35%
Terramycin	58%
Doxycycline	45%

RECOVERY RATE

Tissue (chicken, pork)	85% \pm 20%
Honey	85% \pm 20%

LIMIT OF DETECTION

A: Chicken

Tetracycline	0.4 ppb
Minocycline	0.4 ppb
Rolitettracycline	0.4 ppb
Aureomycin	0.4 ppb
Demeclocycline	1.2 ppb
Terramycin	0.8 ppb
Doxycycline	1 ppb

B: Honey, pork

Tetracycline	0.5 ppb
Minocycline	0.5 ppb
Rolitettracycline	0.5 ppb
Aureomycin	0.5 ppb
Demeclocycline	1.5 ppb
Terramycin	1 ppb
Doxycycline	1.2 ppb

PRECISION

Intra-assay Precision (Precision within an assay): CV%<10%

Three samples of known concentration were tested twenty times on one plate to assess.

Inter-assay Precision (Precision between assays): CV%<10%

Three samples of known concentration were tested in twenty assays to assess.

LIMITATIONS OF THE PROCEDURE

- The kit should not be used beyond the expiration date on the kit label.
- Do not mix or substitute reagents with those from other lots or sources.
- Any variation in operator, pipetting technique, washing technique, incubation time or temperature, and kit age can cause variation in binding.
- This assay is designed to eliminate interference by soluble receptors, binding proteins, and other factors present in biological samples. Until all factors have been tested in the Immunoassay, the possibility of interference cannot be excluded.

MATERIALS PROVIDED

Reagent	Quantity
Assay plate (96 tests)	1
Concentrated Standard (81 ppb)	1 x 1 mL
High Concentration Standard(100 ppb)	1 x 1 mL
HRP-conjugate	1 x 7 mL
Antibody	1 x 7 mL
Substrate A	1 x 7 mL
Substrate B	1 x 7 mL
Stop Solution	1 x 7 mL
Wash Buffer(20x)	1 x 15 mL
Sample Extraction(10x)	2 x 50 mL
Standard Redissolving Solution	1 x 30 mL
Adhesive Strip	4
Instruction Manual	1

STORAGE

Unopened kit	Store at 2 - 8°C. Do not use the kit beyond the expiration date.
Opened kit	May be stored for up to one month at 2 - 8° C.

***Provided this is within the expiration date of the kit.**

STANDARDS PREPARATION

Take 6 x 1.5 mL tubes for standard preparation, number: S6-S1, add 950 μL 、600 μL 、600 μL 、600 μL of Standard Redissolving Solution into corresponding tube. Take 50 μL of Concentrated Standard (81 ppb) into S6, shake well, the concentration of S6 is 4.05 ppb. Take 300 μL of S6 solution into S5 tube and obtain concentration of S5 is 1.35 ppb. Operate as above steps. Finally we can get standards with different concentrations as below.

Number	Standard Redissolving Solution(μL)	Add the solution (μL) into corresponding tube	Concentration (ppb)
S6	950	50 μL of Concentrated Standard (81 ppb)	4.05
S5	600	300 μL of S6	1.35
S4	600	300 μL of S5	0.45
S3	600	300 μL of S4	0.15
S2	600	300 μL of S3	0.05
S1	/	/	0

OTHER SUPPLIES REQUIRED

- Microplate reader capable of measuring absorbance at 450 nm.
- An incubator which can provide stable incubation conditions up to 25°C.
- Squirt bottle, manifold dispenser, or automated microplate washer.
- Absorbent paper for blotting the microtiter plate.
- Single-channel micropipette(20 μL -200 μL 、100 μL -1000 μL)
- 30 μL -300 μL multichannel micropipette
- 100 mL and 500 mL graduated cylinders.
- Deionized or distilled water.
- Pipettes and pipette tips.
- Test tubes for dilution.
- Methanol

PRECAUTIONS

The Stop Solution provided with this kit is an acid solution. Wear eye, hand, face, and clothing protection when using this material.

Note:

- **Kindly use graduated containers to prepare the reagent.**
- Bring all reagents to room temperature (20-25°C) before use for 30min.
- Only the disposable tips can be used for the experiments and the tips must be changed when used for different reagents.
- Distilled water is recommended to be used to make the preparation for reagents. Contaminated water or container for reagent preparation will influence the detection result.

REAGENT PREPARATION

- **Extraction Solution A:** Take 50 mL of **Sample Extraction (10x)** into 450 mL deionized or distilled water, shake well. (If crystals have formed in the concentrate, warm up to room temperature and mix gently until the crystals have completely dissolved.)
- **Extraction Solution B:** Take 50 mL of **Methanol** into 450 mL of **Extraction Solution A**, shake well.
- **Extraction Solution C:** Take 100 mL of **Methanol** into 270 mL of **Extraction Solution B**, shake well.
- **Wash Buffer (1x):** If crystals have formed in the concentrate, warm up to room temperature and mix gently until the crystals have completely dissolved. Dilute 15 mL of **Wash Buffer (20x)** into 285 mL deionized or distilled water to prepare 300 mL of **Wash Buffer (1x)**. Keep it at 4°C for one month.

Note:

1. CUSABIO is only responsible for the kit itself, but not for the samples consumed during the assay. The user should calculate the possible amount of the samples used in the whole test. Please reserve sufficient samples in advance.
2. If the samples are not indicated in the manual, a preliminary experiment to determine the validity of the kit is necessary.
3. Please predict the concentration before assaying. If values for these are not within the range of the standard curve, users must determine the optimal sample dilutions for their particular experiments.

SAMPLE COLLECTION AND STORAGE

A. Chicken

1. Weigh $1.00 \pm 0.05\text{g}$ of the homogenized chicken sample into 50 mL centrifugal tube.
2. Add 8 mL of **Extraction Solution A**, shake properly for 3 min.
3. Centrifuge at above 4000 r/min for 10 min at room temperature.
4. Take 50 μL of supernatant sample for further analysis.

Dilution factor of the samples: 8

B. Pork

1. Weigh $1.00 \pm 0.05\text{g}$ of the homogenized sample into 50 mL centrifugal tube.
2. Add 10 mL of **Extraction Solution B**, shake properly for 3 min. Centrifuge at above 4000 r/min for 10 min at room temperature.
3. Take 50 μL of supernatant sample for further analysis.

Dilution factor of the samples: 10

C. Honey

1. Weigh $1.00 \pm 0.05\text{g}$ of the honey sample, put into 50 mL centrifugal tube.
2. Add 10 mL of **Extraction Solution C**, shake properly for 3 min. Centrifuge at above 4000 r/min for 10 min at room temperature.

3. Take 50 μ L of supernatant sample for further analysis.
Dilution factor of the samples: 10

ASSAY PROCEDURE

Bring all reagents and samples to room temperature (20–25°C) before use. Centrifuge the sample again after thawing before the assay. It is recommended that all samples and standards be assayed in duplicate.

1. Prepare all reagents and samples as directed in the previous sections.
2. Determine the number of wells to be used and put any remaining wells and the desiccant back into the pouch and seal the ziploc, store unused wells at 4°C.
3. Add 50 μ L of **Standard** or **Sample** per well. Standard and Samples need test in duplicate.
4. Then add 50 μ L of **HRP-conjugate** to each well and 50 μ L of **Antibody** to each well. Cover the microtiter plate with a new adhesive strip and mix well, then incubate for 30 min at 25°C.
5. Aspirate each well and wash, repeating the process 4-5 times. Wash by filling each well with 250 μ L of **Wash Buffer (1x)** using a squirt bottle, multi-channel pipette, manifold dispenser, or autowasher, and let it stand for 15-30 seconds, complete removal of liquid at each step is essential to good performance.
6. Add 50 μ L of **Substrate A** and 50 μ L of **Substrate B** to each well, mix well. Incubate for 15 minutes at 25°C. **Protect from light.**
7. Add 50 μ L of **Stop Solution** to each well, gently tap the plate to ensure thorough mixing.
8. Determine the optical density of each well within 5 min, using a microplate reader set to 450 nm (Recommend to read the OD value at the dual-wavelength: 450/630 nm within 5 min).

Note:

1. The final experimental results will be closely related to validity of the products, operation skills of the end users and the experimental environments.
2. Samples or reagents addition: Please carefully add samples to wells and mix gently to avoid foaming. Do not touch the well wall as possible. For each step in the procedure, total dispensing time for addition of reagents or samples to the assay plate should not exceed 10 minutes. This will ensure equal elapsed time for each pipetting step, without interruption. Duplication of all standards and specimens, although not required, is recommended. To avoid cross-contamination, change pipette tips between additions of each standard level, between sample additions, and between reagent additions. Also, use separate reservoirs for each reagent.
3. Incubation: To ensure accurate results, proper adhesion of plate sealers during incubation steps is necessary. Do not allow wells to sit uncovered for extended periods between incubation steps. Once reagents have been added to the well strips, DO NOT let the strips DRY at any time during the assay. Incubation time and temperature must be observed.
4. Washing: The wash procedure is critical. Complete removal of liquid at each step is essential to good performance. After the last wash, remove any remaining Wash Solution by aspirating or decanting and remove any drop of water and fingerprint on the bottom of the plate. Insufficient washing will result in poor precision and falsely elevated absorbance reading. When using an automated plate washer, adding a 30 second soak period following the addition of wash buffer, and/or rotating the plate 180 degrees between wash steps may improve assay precision.
5. Controlling of reaction time: Observe the change of color after adding Substrates (e.g. observation once every 10 minutes). Substrates should change from colorless or light blue to gradations of blue. If the color is too deep, add Stop Solution in advance to avoid excessively strong reaction which will result in inaccurate absorbance reading.
6. Substrates are easily contaminated. Substrates should remain colorless or light blue until added to the plate. Please protect it from light.
7. Stop Solution should be added to the plate in the same order as the Substrates. The color developed in the wells will turn from blue to yellow upon addition of the Stop Solution. Wells that are green in color indicate that the Stop Solution has not mixed thoroughly with the Substrates.

CALCULATION OF RESULTS

There are two methods to judge the results: the first one (A) is the rough judgment, while the second (B) is the quantitative determination. Note that the OD value of the sample has a negative correlation with Tetracyclines in the sample.

A:

Compare the sample average absorbance values with standards values, the Tetracyclines concentration in the samples can be concluded. For example, the absorbance value of sample 1 is 0.3, the absorbance value of sample 2 is 1.0; absorbance values of standard are: 2.243, 1.816, 1.415, 0.74, 0.313, 0.155 and the corresponding concentrations are: 0 ppb, 0.05 ppb, 0.15 ppb, 0.45 ppb, 1.35 ppb, 4.05 ppb; then the Tetracyclines in sample 1 and sample 2 are 1.35 ppb-4.05 ppb and 0.15 ppb-0.45 ppb; Lastly the reader is multiplied by the corresponding dilution factor of each sample and the actual concentration of sample is obtained.

B:

The mean values of the absorbance values obtained for the standards and the samples are divided by the absorbance value of the first standard (zero standard) and multiplied by 100%. The zero standard is thus made equal to 100% and the absorbance values are quoted in percentages.

$$\text{Absorbency value (\%)} = \frac{B}{B_0} \times 100\%$$

B —the average absorbance value of the sample or standard

B₀ —the average absorbance value of the 0 ppb standard

To draw a standard curve: Take the absorbency value of standards as y-axis, semi-logarithmic of the concentration of the Tetracyclines standards solution (ppb) as x-axis.

The Tetracyclines concentration of each sample (ppb), which can be read from

the calibration curve, is multiplied by the corresponding dilution factor of each sample followed, and the actual concentration of sample is obtained. (The software offered together will facilitate the calculation process, it's suitable for accurate and fast analysis of large scale samples, please contact us).

Note:

- Discard the substrate with any color that indicates the degeneration of this solution; when the absorbance value of standard solution 0 of less than 0.5 indicates its degeneration.
- The optimum reaction temperature is 25℃, and too high or too low will result in the changes in the absorbance value and detecting sensitivity.